

Chord Poly Wireless Streamer

Connecting to a WiFi Network



This guide will help you attach Poly onto a 2.4Ghz WiFi network. To do so we need access to Poly so we can tell it what WiFi network to connect to. To complete this process Poly will need a 2.4Ghz WiFi network to connect to, a phone, tablet or a computer. You will need to know the name(SSID) of the 2.4Ghz WiFi network you want Poly to connect to and its password. If your network does not have a password you will need to create one for it. Poly should also be fully charged before setup is attempted. Poly must be setup with WiFi before Bluetooth can be used.

What You Need


- 2.4Ghz WiFi network
- Phone, tablet or computer
- Network name (SSID) and password
- Full battery charge

Instructions

1. Attach your fully-charged Poly to your Mojo and turn on the Mojo.



2. The P.status light will flash from blue to green when Poly enters Access Point Mode. It is now ready to be configured.



**If the P.status light is not flashing blue and green, use the included Sim Card Tool to press the button inside the Config port hole for 7 seconds. Remove the Sim Card Tool and wait 10 seconds for the flashing to begin.*




Chord Poly Wireless Streamer

Connecting to a WiFi Network



- In Access Point Mode, Poly creates its own wireless network. Connect to this Wi-Fi network from a computer or mobile device to set up and control your Poly. Look for Poly's network in your device's WiFi settings and connect to it. Examples of different systems are shown below.


Mac OS-X




Windows



iOS



Android



Chord Poly Wireless Streamer

Connecting to a WiFi Network





- Once connected to Poly's Hotspot a web browser pop-up window will appear. Scroll down in this window to **Poly Mode Settings**.

There are two primary Play Modes:

Roon Mode: Poly will only work as a Roon endpoint.

Other Mode: For everything else, including UPnP/DLNA, MPD, Airplay, and Bluetooth. If you are not using a Roon, choose **Other**.

Do not click save until next step.



**All three fields must be completed or Poly will not set up properly.*

Chord Poly Wireless Streamer


Connecting to a WiFi Network



Chord Electronics Ltd.

- From **Poly Mode Settings**, select **WiFi Settings** and enter the nickname, network ID (SSID), and password for your wireless network.

Check the box next to Reboot on save, then click the Save button.



*Cell 1: Enter a network name that will help you remember which network you are connecting to or where it is located, such as a room or building name.

*Cell 2: Enter the name of your wifi network exactly as it appears in the WiFi network list and in your network configurations.

- After clicking Save, a pop-up confirmation will appear and remain on-screen while the Poly reboots and attempts to connect to the WiFi network.

If Poly successfully connects to the network, the P.status LED will be solid. (The color will vary depending on the charge of the battery.)

