



XP-22 Owner's Manual

WARNING

Water and moisture: This device should not be used near water (as per example, near a bathtub, washbasin, kitchen sink, laundry tub, wet basement or swimming pool). Care should be taken such that objects do not have the opportunity to fall, and that liquid is never spilled onto or into the device enclosure through openings.

Power Sources: This device must be connected to a mains power source in strict accordance with the supplied product owners manual. Please verify that the AC mains voltage specified in the product manual matches those requirements indicated on the unit and the AC voltage provided to your location by the power company. The product **MUST** be connected to a MAINS socket outlet with a protective earthing connection.

Power Cords: Pass Labs provides a power supply cord that meets all legislated requirements for the market in which the product was originally sold. If you choose to substitute an after-market product we urge you to choose one that is fully safety rated by the necessary local authority.

Power supply cords should be routed so that they are not likely to be walked on, abraded, or pinched by items placed on or against them, paying particular attention to cords where they enter plugs or exit from a device. Never under any circumstance insert a cut or damaged power cord into a mains power socket. Cables should never be connected / disconnected with equipment powered up. Failure to heed this warning may damage or destroy equipment.

Ventilation: Power-amplifiers run warm, but you should be able to place your hands on them without discomfort. You must allow for this heat in installation, by providing for free air circulation around the product. Leave a minimum of 6" of space around the amplifier. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.

Other Warnings:

No naked flame sources, such as lighted candles, should be placed on the apparatus; This amplifier is suitable for tropical climates under 2000m and ambient temperatures of 40 degrees C or less.

Servicing: To reduce the risk of fire, electrical shock or other injuries, the user should not attempt to service the device beyond that which is described in the operating instructions. All other servicing must be referred to qualified service personnel.

For Units With Externally Accessible Fuse Receptacle: Unplug the device from all sources of power before changing or inspecting any fuse. Replace fuse with one of same physical size, type and rating as that specified by the manufacturer for that product.

Country Specific Warnings:

China: For use at altitude 2000m or lower.

Norway: Apparatet må tilkoples jordet stikkontakt.

Sweden: Apparaten skall anslutas till jordat uttag.

Finland: Laitte on liitettävä suojakoskettimilla varustettuun pistorasiaan.

Denmark: Apparatets stikprop skal tilsluttes en stikkontakt med jord, som giver forbindelse til stikproppens jord.

Trademarks: "Pass", "**PASS**", "Pass Labs", "Pass Laboratories", "Supersymmetry", "Aleph", and "Zen" and are all registered trademarks of Pass Laboratories, Inc., and all rights thereto are protected by law.

Introduction:

At Pass Labs we don't change our products unless we feel that the changes are significant improvements over previous versions. Because of this we see typical product life spans of seven to eight years.

We are constantly working on and listening to new things and increasing our knowledge of circuits and components on sound. Eventually we find some things worth putting into production because they are significant enough. That time has come with a new series of preamplifiers.

The new XP-22 starts with a new power supply. It uses two efficient toroidal transformers with both an electrostatic and Mu metal shield along with vacuum impregnating and epoxy fill. This gives us a very quiet transformer both electrically and mechanically.

The power supply circuitry itself is also lower noise and has additional filtering, a little more complicated but worth it.

The XP-22 uses the single stage volume control borrowed from the XS line preamp. This gives us one hundred 1 dB steps with lower noise and distortion while removing some signal path parts.

The gain circuitry continues to use our favorite transistors from Toshiba but has a larger higher biased output stage similar to the XS preamplifier auto bias. This makes longer and multiple cable runs easier to drive and gives us the advantage of simplifying our single ended output circuitry while increasing performance.

Overall this makes for a quieter more neutral, musical and versatile control center for your system.

Thank you for purchasing this preamp. It is my sincere hope that you will enjoy its sound as much as we do.

Pass Labs

Setup:

Please read and understand the operational instructions and safety issues associated with this product. We go through great effort to make a soundly engineered, and superbly performing product of lasting durability.

We understand that things infrequently go wrong, if you have any questions or problems please contact either your dealer or the factory, we are here to support the product and you, the user.

As with all audio electronics the power cable should be the last thing attached and the first one removed any time you hook up or remove equipment from the signal chain. The JAE umbilical cable should never be connected or removed without turning the XP-22 off from the rear power switch or unplugging the AC power cord.

The control can be placed on top of the power supply but for the best performance they should be separated a little. Putting the power supply on a lower shelf works great.



The preamplifier's voltage and current rating are indicated by affixed tag on the rear of the preamplifier. The preamplifier typically draws 45 watts during operation. Please verify that the indicated voltage requirement of this preamplifier is consistent with the utility voltage at your location.

We have provided a standard IEC AC power cord that fits into the IEC 320 line receptacle at the rear of the preamplifier chassis. The preamplifier is equipped for operation with an earth ground provided by the users AC outlet. Do not defeat this ground.

There are a total of five inputs and a tape loop. Two of the five inputs are balanced XLR only. The other three inputs are single-ended only as is the tape loop. There are two pairs of outputs available with identical gain structure. One pair Balanced, two pairs of single-ended.

Balanced inputs and outputs are via XLR connectors. Single-ended inputs and outputs are via RCA connectors. On the XLR connectors, pin 1 is grounded, pin 2 is the positive signal, and pin 3 is the negative signal. Left channel RCA connectors are marked with "L". Right channel RCA connectors are marked with "R". In a similar fashion balanced XLR inputs and outputs are marked with "L" for left and "R" for right channel.

Operation:

In use the XP-22's front panel controls and alphanumeric display are quite straight forward, and intuitive. We encourage you to become familiar with their operation prior to establishing any input connections with this unit.

After all the inputs and outputs are connected and double checked, you can now turn on the preamp by means of the power switch located next to the AC inlet, on the rear of the power supply.

The left most button on the front panel is Mute. Pressing this button toggles between mute on and mute off. Mute on removes signal from the output of the preamp.

The front panel mode switch cycles the preamplifier display through 2 different levels and off. These two functions are as follows: Bright, Dim and Off. Using any functions with the display "off" will momentarily bring the display back up to its dim setting.

The two Select switches (designated by left and right pointing arrows) then alter the displayed active input, 1 through 5.

Input 5 is unique in that it is linked with the Home Theater (Unity Gain) function. (The HOME THEATRE FUNCTION is discussed at length later in this manual.) The two select arrows logically control selections of the various inputs to the preamplifier.

Before selecting the theatre pass through (pass thru) option, it is imperative that the input device on input number 5 has its gain set to minimum. Failure to follow this precaution could result in a volume level intolerable to both ears and speakers. (The standard 2 volt source component, with the pre-amp set to 0 dB, will drive most power amps to full rated output.)

As an added precaution when "pass through" is selected the volume ramps upto 89. This is to prevent nasty surprises when "pass thru" is selected accidentally. The ramp up sequence can be stopped at any time by hitting any button on the remote.

The theater pass through function bears special attention, this function is only available as direct access through the hand held remote control. This function is associated only with input number 5 and has two positions selected with the "pass thru" button on the remote; those two positions, on and off. This function is useful in that it allows the preamplifier to function as a unity buffer (0dB gain at volume step 75) for use with components that best function with their own volume controls, such as surround processors.

When the right-front and left-front outputs of the processor are routed through input 5 of the XP-22 (with the gain of the XP-22 set for Unity), the volume will be under full control of the processor and the XP-22's action will be totally transparent. When the

user chooses this setting the software sets the XP-22's gain to the unity gain setting, regardless of how it was previously configured.

When at Unity both left and right level controls on the XP-22 will have a displayed value of 89 (0 dB), and any previous balance settings will be set-aside into a temporary registry. Both of these default conditions are intentional, and intended to make the most advantageous use of your source electronics. You may also set any input to unity (0 dB) by selecting low gain and setting the volume at step 89.

The electronic volume control allows greater than 90dB range and is driven by a micro-controller that reads the optical encoder serving as a front panel volume control. In this manner tracking of the volume of the two balanced channels is possible with accuracy unavailable on any ordinary volume control, assuring precise level steps and high common mode rejection in balanced circuits.

Wayne Colburn's exceptional volume control in conjunction with the fluorescent display gives the user ability to replicate volume levels with absolute accuracy in steps of roughly 1 dB.

Note: The way the volume control is designed, you may need to be at step 40 or 50 before you can hear anything.

Don't be afraid to turn the volume up to 60, 70, 80 etc. The volume control is an attenuator so the higher up you use it the more of the original signal is used.



This remote is designed to operate several pieces of Pass Labs electronics, not all of the functions available on this remote will be applicable to your Pass Laboratories XP-22.

Power: is not used with the XP-22. This is used on other products and has no effect on this product.

Mute: pressing mute once will quiet the pre-amplifier outputs; pressing mute a second time will return you to the previous volume control setting

Input Selection: Pressing 1,2,3,4,5 will immediately move the input selection to that input selection; volume and balance settings will not be disturbed.

Volume: Pressing the increase (^) button or the decrease (v) button will shift the volume setting 1dB, holding a button down will increase or decrease the level until such time as you either release pressure on the button or reach the limits of the volume control.

Balance: Pressing balance left (<) or balance right (>) will increase the level in the left or right speaker, depending upon which button is pushed.

Tape: Pressing the tape button selects the tape loop and displays INPUT TAPE † with volume at 000. Push tape again get you out of tape mode.

Pass Thru: Pushing this button twice, sets the pre-amplifier to volume step 89 (0 dB) and input 5. As an added precaution when "pass through" is selected the volume ramps upto 89. This is to prevent nasty surprises when "pass thru" is selected accidentally. The ramp up sequence can be stopped at any time by hitting any button on the remote. The button must be pressed again to exit "Pass Thru" and unlock the other command selections.

Display: The default setting for the display is "bright", pressing the display button once changes the display to its "dim" or "low intensity" setting, pressing the button a second time selects "off" for the display. When "off" is selected any other control function will cause the display to indicate product operational status for approximately 7 seconds and then the display will once again blank. Pressing the display button a third time cycles back to a "bright display"

Ext amp on: Selection of "Ext Amp On" applies 12Vdc to a two conductor 3.5mm TS (tip-sleeve) connector on the rear of the XP-22 control chassis. This is intended to supply a trigger voltage that will turn on associated equipment such as power amps. As per convention + voltage is applied to the tip contact and - voltage is applied to the sleeve contract. Check the owners manual of your pre-amp to see if this function in compatible.

Maintenance:

Leave it on or turn it off: The product is designed to be left on all the time. The exception to this might be a case where the preamp will not be used for an extended time - in that case it can be turned off.

Cleaning: The finish can be damaged by harsh cleaners and abrasive cloths. We find a damp soft cloth works best. You can also use a mild solution of Windex or white vinegar but be careful to avoid the acrylic window. The acrylic window should only be cleaned using "plastic cleaner & polish".

Remote batteries: The two AAA batteries should be replaced every six months at least. The batteries are located under the remote back. This is held in place with four 4-40 Phillips flat head screws. Please note the polarity of the batteries, putting them in wrong could cause damage.

Replacing the fuse: The fuse should only be replaced with the same type and size as indicated on the rear. Audio Specialty FUSE: NOTE: The "Overload" and "Time Delay characteristics" will differ slightly (due to the different metallurgy of the fuse elements) between commercial grade and audio grade fuses. We can't guarantee that your audiophile grade fuse, won't blow at a different in-rush current threshold, than your stock commercial fuse. Use of other than approved fuses, may invalidate your product warranty and result in product damage.

How to replace the fuse:



XP-22 Specs:

Power consumption:	40 watts
Gain:	9.6dB Balanced
Output Impedance:	25 Ohms RCA, 50 Ohms XLR
Input Impedance:	22K Ohms
Frequency response:	+/- 0.05 dB 10Hz to 20KHz, -2dB @ 150KHz
Crosstalk	> 100dB
Residual Noise	2uV RMS, SN -125dB ref max out
THD	< 0.001 @ 1V 1KHz
Dimensions:	17" w x 12.5" d x 4" h times two
Weight:	40 lbs

Warranty Information

We go through great effort to make a soundly engineered, and superbly performing product of lasting durability. But we also understand that things infrequently go wrong, if you have any questions or problems please contact either your dealer or the factory, we are here to support the product and you, the user.

All Pass Laboratories products purchased new from an authorized Pass Laboratories dealer in North America are covered by a transferable, limited 3-year warranty. This warranty includes all parts and labor charges incurred at the factory or factory specified repair facility, exclusive of any subsequent or consequential damages. Damage due to physical abuse is specifically excluded under this warranty.

For this warranty to apply the customer is responsible for returning the product unmodified to the factory within the specified warranty period. The customer assumes all responsibility for shipping and insurance to and from the factory or a factory specified repair facility. The conditions and stipulations of this Pass Laboratories warranty only applies to units originally sold new through an authorized dealer. Warranty on factory repair is 60 days and covers only the scope of the original repair.

Non-North America customers should consult with their original Pass Labs dealer or distributor for warranty repair instruction prior to contacting the factory or shipping product to the factory for repair.

Non-North American product must be returned to the country of origin for warranty service. Foreign distributors are only required to offer warranty service on Pass Laboratories product that they have imported, verifiable by serial number.

Please note: Conditions of warranty service and customer rights for product purchased outside the United States may vary depending upon the distributor and local laws. Please check with your local distributor for specific rights and details.

Any modifications to Pass Laboratories products that have not received written factory approval nullify all claims and void all provisions of the warranty and liability by the maker or authorized distributor. Should a modified product be returned to the factory for repair the owner will be required to pay all necessary charges for the repair in addition to those charges required to return the product to it's original configuration.

In the case of safety issues, no product shall be returned to the customer without those safety issues being corrected to the most recent accepted standards.

Removal or alteration of original Pass Labs serial numbers voids the factory warranty. Product with altered or missing serial numbers will be suspect as counterfeit or stolen product.

Pass Laboratories will not repair or in any way indemnify any counterfeit or cloned product. Pass Laboratories does not offer products in voltages intended for international markets either to authorized Pass Labs dealers or to third parties located in the United States or Canada.

PASS[®]

Pass Laboratories Inc.,
13395 New Airport Rd.,
Suite G, Auburn, CA 95602
530.878.5350
passlabs.com